

READY TO RIDE ASSEMBLY INSTRUCTIONS

Congratulations on your new PUBLIC Mini balance bike. By following a few simple steps your PUBLIC Mini bike will be ready to go! Just a few points we'd like to mention before you begin:

- This product is intended for ages 3 to 5.
- Always wear a helmet. Some states require riders under 18 to wear a helmet. Please check your local laws.
- Adult supervision is required at all times. Never leave a child unattended while riding.
- Must be assembled by an adult.
- This product conforms to the toy safety requirements of ASTM F963 and CPSIA 101.
- Not suitable for children under 36 months old due to small parts choking hazard.
- Packaging material presents a choking hazard, please keep away from small children.

Step 1 – Unboxing

- Start by carefully removing bike from the box (**Figure 1**).
- Remove all packaging. Be careful to recycle all zip ties and plastic pieces, as these may present a choking hazard.
- Locate the hex (allen) wrench, zip tied to the stem (**Figure 2**). Set this aside for use in bike assembly.

Step 2 – Inserting the stem and handlebars

- With the packaging removed let's install the stem and handlebars into the fork. First, make sure the fork is oriented in the correct direction, angled forward, sloping away from the center of the bike (**Figures 3 & 4**).
- Now we are ready to install the stem and handlebars. Insert the stem into the fork (**Figure 5**), aligning the handlebars so that they are perpendicular to the front wheel.
- Be aware the stem has a "minimum insertion line" marked on it (**Figure 6**). The stem and bars should be inserted far enough into the fork of the bike that these lines are not visible.
- With the handlebars set at the desired height, tighten the bolt on the top of the stem (clockwise) with the hex wrench (**Figure 7**).

Step 3 – Adjust the seat height

- Like the stem, the seat post has a minimum insertion line (**Figure 8**). The seat should always be low enough that the minimum insertion line is not visible. If you need to raise the seat higher than the minimum insertion line allows, contact us to order a longer seat post.
- Loosen the seat post clamp bolt (counter-clockwise) (**Figure 9**). Set the seat to the desired height and tighten the seat post clamp (clockwise).

Step 4 – Check tire inflation

- The tires should arrive already inflated. If they appear flat, please inflate before riding, with no more than 10-20 PSI of pressure. Tires should be checked and inflated weekly.
- **WARNING: DO NOT** inflate with a gas station air hose or powered air compressor! Overinflation will permanently damage tires. Only use a bicycle pump to inflate tires.

Step 5 – Ready to roll

- Congratulations! Your PUBLIC Mini is ready to ride!

Have Questions? Contact us

If you run into any problems or have any questions please give us a call at + 1 888 450 0123 10am to 6pm PST Monday – Friday, or send an email to customerservice@publicbikes.com.

